



UL Emergency Release: Instructions For Adding In Field

1. Remove both back service doors
2. Remove center divider
3. Remove top and bottom stainless panels
4. Remove interior stainless cover around time locks (save as template)
5. Drill out rivets on outer edge of interior stainless trim brace
6. Remove trim brace (Allen head bolt)
7. Remove day lock support on right side of lock
8. Remove time lock bar
9. Remove time lock completely from door
10. Use set screw provided (A) for locking mechanism and pull cable through and secure tightly. Do not run cable past mechanism.
11. Place emergency rod provided (B) in day lock bar. Screw in set screw tight, place rod over set screw, run cable
12. Run cable from A to B
13. Place cap assembly (C) over emergency rod and secure tightly. Use spacers if required. Rod should turn easily.
14. Verify that cable is pulled tight
15. Use Emergency handles provided to test the mechanism
16. Remove handles after testing
17. Reinstall time lock completely from door
18. Reinstall time lock bar
19. Reinstall day lock support on right side of lock
20. Reinstall trim brace (Allen head bolt)
21. Screw outer edge of interior stainless trim brace to secure
22. Reinstall new interior stainless cover around time locks use old as template to locate screw holes
23. Reinstall top and bottom stainless panels
24. Reinstall center divider
25. Slide each Emergency handles in holes provided in new stainless steel cover, verify that they are seated correctly and secure with set screws provided
26. Verify that the mechanism works
27. Add direction stickers as required
28. Add instruction sticker
29. Reinstall both back service doors
30. Instruct customer on how to use